This is the Folding Mechanism you will receive



Use Bull Nose pliers to remove rivet studs. (Multigrip pliers to re-assemble)



Unscrew screws from inside mounting bracket



Remove Brake assembly by unscrewing the brake from the legs.



Pull Top and bottom sections away from the folding mechanism.



Now you're ready to re-assemble. Just reverse the steps used to take it apart.

Make sure you use the new plastic pieces that came with your folding mechanism.

